

Customer Instructions

DEODORIZER-OZONE GENERATOR



Operating Instructions

1. Place unit:
 - a) *As high as possible in the room for complete purification. Ozone is heavier than air and will drift down, neutralizing offending agents as it does.*
 - b) *Near source of the worst odors. Ozone concentration is highest as it exits the unit.*
 - c) *In the area most heavily used.*
 - d) *Near a cold return vent (if you are treating entire home), to thoroughly circulate clean air.*
2. Turn the timer dial clockwise to the desired run time, from 15 min. to 12 hours. Push or turn the round knob clockwise to turn on the unit. Continue to turn the knob until the desired output is achieved. A bleach like odor is normal.
3. For continuous use, turn the timer **COUNTER-CLOCKWISE** to “hold.”
4. To deodorize a vehicle, clean vehicle interior, making sure that it is completely 100% dry, place unit in car and roll down windows 1/2”. Run ozone machine for 30 to 45 minute. Repeat if necessary.

Great for use in small & large areas. A quick shock treatment can turn a smoking room into a non-smoking room, or permanently remove painting or pet odors. Coverage is up to 6000 sq. ft. for odors and 1000 sq. ft. for mold.

These instructions are intended as a helpful reminder. They do not replace the full operating instructions found in the owners manual, which is available at the rental counter.

A to Z Equipment Rentals & Sales - 4 locations in the Phoenix Arizona Metro Area
If you like this piece of equipment, inquire about purchasing it!

If equipment does not work properly, notify office at once - Phoenix, 602-955-5100 • North Valley., 602-992-1150 •
• East Valley, 480-539-8700 • West Valley, 623-925-0200 •